

Caution

Avoid Contact with eyes and skin.
Do not ingest or inhale. Harmful if swallowed.

First Aid

Eyes & Skin: Flush with water for 15 minutes.
Inhalation: Remove to fresh air directions on
Ingestion: If conscious and alert, drink large quantities of water. Do not induce vomiting. If any irritation persists, seek medical attention.

Precaución

Evite el contacto con los ojos y la piel.
No ingiera o inhale. Dañino si se traga.

Primeros Auxilios

Ojos y Piel: Enjuague con abundante agua por 15 minutos.
Inhalación: Remuevase a un lugar con aire fresco.
Ingestión: Si esta conciente y alerta, tome cantidades abundantes de agua. No induzca el vomito.
Si cualquier irritación persiste, busque rápidamente de la ayuda médica.

HMIS Codes	
Health	0
Flammability	0
Reactivity	0
Personal Protection	A

P.I.N – A - 120



D-FACTOR EXPRESS SHINE DETAIL TREATMENT

Net Contents: 32 oz. (QT)

Keep Out of Reach of Children

Encore Industrial Products, LLC
PO Box 941119, Houston, TX 77094
281-944-4777 or 1-877-703-3044

D-Factor is a labor saving state of the art extreme high gloss detail spray treatment. Simply spray D-Factor on the vehicle, let sit for approximately 5 minutes and buff with a clean cloth or pad to a ultra-high gloss shine. Can be buffed by hand or by orbital buffer.

Directions for Use: D-Factor is an RTU formula (ready to use)

Step 1: Clean vehicle with **Encore Industrial's Fleet Wash** and dry with lint free cloth or air dry.

Step 2: Spray D-Factor using the trigger sprayer included with the product. Let dry on surface for up to 5 minutes, depending on ambient temperature.

Step 3: Wipe off D-Factor with a clean cloth or orbital buffer to an ultra-high gloss shine.

- **Spray and Wipe Formula**
- **Use on Body, Glass and Chrome**
- **Creates a Brilliant Shine**
- **Labor Saving Formula**
- **Protects Against Harmful UV Rays**
- **Safe on Painted Metal, Fiberglass, Plastic Glass, Plexi Glass and Most Vehicle Surfaces.**