

D-FACTOR

Product Highlights

D-Factor is a labor saving state of the art extreme high gloss detail spray treatment. Simply spray D-Factor on vehicle, let sit for approximately 5 minutes and buff to an ultra high gloss with a clean cloth or buffing pad. Can be buffed by hand or by orbital buffer.

CAUTION

Avoid Contact with eyes and skin. Do not ingest. Harmful if swallowed.

First Aid:

Eyes & Skin: Flush with water for 15 minutes.

Ingestion: If conscious and alert, drink large quantities of water. Do not induce vomiting. If any irritation persists, seek medical attention.



P.I.N. A-120
ENCORE INDUSTRIAL
PRODUCTS, LLC

P.O. Box 300
 Barker, TX 77413
 281-944-4777 or 1-877-703-3044
 www.encoreindustrial.com



D-FACTOR

Express Shine Detail Treatment

- *Helps Protect Against UV Damage*
- *Prevents Against Damaging Water Spots*
- *Creates Showroom Shine*

KEEP OUT OF REACH OF CHILDREN

CAUTION:

Avoid Contact with eyes and skin.
Do not ingest. Harmful if swallowed.

NET WT. 32 OZ (1 QT)

Directions For Use

D-Factor is an RTU formula (ready to use)

- Step 1:** Clean vehicle with **Encore Industrial's Fleet Wash** and dry with lint free cloth or air dry.
- Step 2:** Spray D-Factor using the trigger sprayer included with product. Let dry on surface for up to 5 minutes, depending on ambient temperature.
- Step 3:** Wipe off D-Factor with a clean cloth or orbital buffer to an ultra-high gloss shine.

- **Spray and Wipe Formula**
- **Use on Body, Glass and Chrome**
- **Creates a Brilliant Shine**
- **Labor Saving Formula**
- **Protects Against Harmful UV Rays**
- **Safe on Painted Metal, Fiberglass, Plastic, Glass, Plexi Glass and Most Vehicle Surfaces.**

FOR PROFESSIONAL USE ONLY

HMIS RATING:

Health	0
Flammability	0
Reactivity	0
Personal Protection	A