

SUPER VALVE FLUSH

P.I.N. I-350 – 5GLP

Health	0
Flammability	1
Reactivity	0
Personal	A

DIRECTIONS FOR USE:

Apply **Super Valve Flush** using a rechargeable spray can or pour directly into opening. Allow product to sit for 5 minutes. Dump out any residual product and let air dry. If the equipment allows blow out with air guns. Once completely dry begin applying new grease or lubricant.

Batch Number: #



Encore Industrial Products, LLC
3502 Bacor Rd., Houston, Tx 77084
281-944-4777 | 1-877- 703-3044
www.encoreindustrial.com



SUPER VALVE FLUSH

INTERNAL VALVE CLEANER

REMOVES THE FOLLOWING:
GREASE & LUBRICANTS
PREVIOUS BUILD UP OF SOLIDS
CONTAMINENTS
DEPOSITS
PREPARES FITTINGS AND
INTERNALS FOR NEW GREASE

Keep Out Of Reach of Children

Net Contents

5 GALLONS

First Aid

Eye Irritation: Flush with water. Consult physician and poison control immediately.

Skin Contact: wash skin with soap and water, if irritation occurs, call physician.

Ingestion: If swallowed be slightly toxic. Consult physician and poison control immediately.

Dispose of in accordance with local, state and federal regulations.



Warning: Harmful if inhaled. Avoid breathing dust/fumes/gas/mist/spray. Use only outdoors or in a well-ventilated area.