DIRECTIONS

PRECAUCION AL USARIO: SI USTED NO LEE INGLES. NO USE ESTE PRODUCTO HASTA QUE SE LA HA EXPLICADO AMPLIAMENTE.

READ ALL DIRECTIONS AND WARNING BEFORE USE. FOLLOW ALL DIRECTIONS EXACTLY, DO NOT use drain opener in or on aluminum, chromes, stainless steel, fiberglass, lead pipes, or non-acid-resistance enamel. Clean spills or drips immediately. Always close connecting drains when using drain opener. Avoid backups. Do not use plunger. Place a bucket or other large, deep container under drain before use. This product is inhibited against attacking most metals.Old piping system may be porous and have defects that are sealed with accumulated organic matter. This product may expose these defects by attacking organic matter, as intended, and cause leaks.


Remove standing water and temper fixture with hot water before applying drain opener. Incorrect use may crack toilet. After tempering, slowly pour the entire pint directly into drain opening. Do not inhale fumes.

FOR USE IN URINALS: Pour the entire pint into urinal drain. And let stand up to 15 minutes or as needed. Stay with urinal while product is working until the blockage or slow drain is opened up. After 15 minutes standing time, slowly add 1 quart of cold water into drain opening and wait another 5 minutes. If line is clear, flush thoroughly with more cold water. Do not allow water to splash. Recommended dosage will open most lines, but if blockage persists, repeat dosage. Use as directed, drain opener will not harm drainage system.


> FOR EMERGENCIES CALL CHEM-TELL: 1-800-255-3924 P.I.N. - B 335



Made with Fume Filter Technology Safe on Most Fixtures and Piping Systems Breaks through Uric Acid & Uric Salt



DANGER!





Contains: sulfuric acid. conc>51%, aqueous solutions, (CAS No) 7664-93-9

NET CONTENTS: 16 FL, OZ, (1 U.S, PINT) 473 mL

PRECAUTIONS









FIRST AID

IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. Immediately call a doctor, IF ON SKIN OR HAIR: Take off immediately all contaminated clothing. Rinse skin with water/shower. Immediately call a doctor. IF INHALED: Remove person to fresh air and keep comfortable for breathing, Immediately call a doctor, IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a doctor

PRECAUTIONS FOR SAFE HANDLING

Wash contaminated clothing before reuse. Absorb spillage to prevent material damage. Store in a wellventilated place. Store locked up on a shelf low to the ground. Store in a corrosive resistant container with a resistant inner liner. Dispose of contents/container to ar approved waste disposal plant. May be corrosive to metals. Wash hands and other exposed areas with mild soap and water before eating, drinking, or smoking, and when leaving work. Provide good ventilation in process area to prevent formation of vapor. Avoid during pregnancy/while nursing.



ENCORE INDUSTRIAL PRODUCTS, LLC PO BOX 300 Barker, TX 77413

1-877-703-3044 or 281-944-4777 www.encoreindustrial.com